



1. **Application:** Apply hi-temp **KO-17** penetrant by spray or brush to a limited area. The area to which the penetrant is to be applied should not be too large, so processing can be completed within penetrant and developer dwell time restraints. The size of the area will vary with inspection temperatures, part geometry, and operator experience.

2. **Dwell:** The penetrant must be allowed to dwell on the part surface to promote the penetrant time to enter any surface flaws. At higher temperatures, penetration occurs more quickly.

225 ^o – 350 ^o F (107.2 ^o C – 176.7 ^o C)	30 seconds
175 ^o – 225 ^o F (79.4 ^o C – 107.2 ^o C)	1-2 minutes
125 ^o – 175 ^o F (51.7 ^o C – 79.4 ^o C)	2-3 minutes
75 ^o – 125 ^o F (23.9 ^o C – 51.7 ^o C)	3-10 minutes
50 ^o – 75 ^o F (10 ^o C – 23.9 ^o C)	10-30 minutes

Allowances must be made for contamination levels and flaw sizes.

3. **Removal:** Wipe the surface with paper or soft clean cloth towels to remove as much **KO-17** as possible from the surface part. Spray **KO-19** remover directly onto the surface of the part in a thin coat and immediately wipe from the part surface. The part is then wiped with a water saturated towel or cloth to remove the last traces of penetrant. Finally a dry wipe is used to remove any water from the part.

4. **Drying:** Use paper or cloth toweling to dry the part's surface thoroughly. Extra drying time before applying developer to heated parts should not be required.

5. **Developing:** **D-350** developer should be sprayed on the part surface from a distance of 6-8 inches immediately after the excess penetrant has been removed and the part has dried. Apply a thin even coat, two or three thin coats are preferred to a single, heavy coat.

6. **Inspection:** Observe the surface for defect indication formation while the developer is applied. Final surface examination should begin within a minute or two after developer application. Surface examination should be completed as quickly as practical, and within ten or fifteen minutes.

Health & Safety

D-350 hi-temp penetrant should be used with adequate ventilation and away from sparks, flame, since it is applied to heated surfaces. Wear protective clothing and equipment. Avoid prolonged or repeated contact with skin. Do not take internally. Consult the MSDS for more safety and health information.